

Right choice for disinfectant of

Vegetables / Fruit Washing / Food Processing / Dairy

Bactafree-S Tablets

Sanitizing Tablets

Sanitation of Salads, Tomatoes, Vegetables
And Also Effective in Food Preparation Surfaces
& Equipments



Directions for use:

APPLICATION	DOSAGE	AVAILABLE CHLORINE	METHOD
Salad, Tomatoes, Vegetables Wash / Disinfectant	2 Tablets in 30 liters of water	50 ppm	# Wash Vegetables with Water. # Prepare a solution as per required Dosage with warm water and wait up to tablet completely dissolved. # Immerse the Vegetables in the solution for at least 5 to 10 min. # Wash with Clean Water.
Food Preparation Areas/ Surface, Wall, Tiles and Equipments, Cutlery, Crockery and Glassware Wash / Disinfectant	2 Tablets in 10 liters of water	150 ppm	# Prepare a solution as per required Dosage with warm water. # Rinse the Prepare solution to the Surface & required Area, Leave for 5 to 10 minutes. # Wash the Surface with Clean water, cloth, brush or mop.

Ensure that the tablet dissolves completely before using solution.

INGREDIENTS: Sodium dichloroisocyanurate

Advantages of Bactafree –S Tablet

- Release chlorine only when dissolved in water.
- Tablet is in a stable form.
- Easy handling & compact storage; No leaks or spillage.
- Bactafree- S an active ingredient having biocidal activity against Gram Positive & Gram Negative bacteria, Bacterial Spores, fungi, algae, viruses etc, also effective in eliminating common diseases such as Typhoid, Cholera, Polio and Diarrhea. Effective against a wide Spectrum of micro-organisms in all water conditions, helping to increase Hygiene Security.
- Resistant to organic spoilage.
- Convenient to use with easy measurement and dissolves quickly in water forming clear disinfecting solution and acidic solution of ph. Effective at short contact time.
- Economical.
- Less corrosive to rubber and stainless steel.
- Yields known level of available chlorine.

PRECAUTIONS:

1. Keep out of children's reach
2. Do not dissolve in strong alkali (over pH 10) or acidic (below pH3) Solution
3. Store away from acids and water
4. Do not place near fire or strong inflammables
5. Do not place in metallic vessel for more than 2 hours
6. Harmful if swallowed
7. Irritating to eyes and respiratory system

Replace the cap securely after use.

STORAGE: Store in a cool and dark place under dry condition. Chlorine contents are stable if stored under room temperature and may reduce depending on storage conditions.

PRECISE HEALTH CARE PVT. LTD

31, Padmavti, 3rd Floor, Damubhai Shukla Colony, Anjli Cross Road, Paldi- Vasna Road, Ahmedabad 380007. Phone: 079- 26612147 / 26631744

Email: precise93@gmail.com